

IColor™ Presto! 2 Step™ Textile Transfer Paper Instructions

AVAILABLE IN LETTER, A4 AND TABLOID PAPER SIZES

Temperature	Time	Paper Setting	Pressure
285°F / 140°C	120 / 30 Seconds	IColor™ 650/600/500 - Media Type: Transparency / Media Weight: UH1 IColor™ 550/540 - Paper Type: Thick to 163g IColor™ 560 - Paper Type: Thick to 105g IColor™ 800 - Paper Type: Thick to 163g/220g	5

The IColor™ Presto! 2 Step™ Transfer Paper is an easy to use media for use with a variety of monochrome, white toner, CMYK Laser/LED printers and copiers. Print black and get white, metallic or neon colors! No cutting or weeding necessary! More durable than foil stamping and easier to use than vinyl!

The white adhesive applied as a result of the 2 step process **increases the adhesion** to your garment for **maximum durability, opacity and vibrancy** on your finished product. Rasterization and breathability integrated into your design, as well as using the garment color as a mask, will enhance the stretch limit and softness of your finished product.

The IColor™ Presto! 2 Step™ Transfer Paper's default pressing temperature is 285°F / 140°C, so some care must be taken when pressing onto some types of synthetic material such as nylon or polyester. **Spandex or Lycra material is not recommended** at this temperature. **You can press as low as 250°F / 120°C** onto the substrate to retain vibrancy and avoid damage caused by excessive heat.

The IColor™ Presto! 2 Step™ Transfer Paper is a **weed-free system**, enabling you to produce detailed, high quality images while dramatically reducing your production time.

Available Color Options:



Finished garments will last between 30 – 50 washes depending on how it's laundered.

- It is recommended to wash finished garments inside out in cold or warm water and low agitation.
- Avoid fabric softener.
- Tumble dry on low setting - For best results, hang to dry.
- If ironing is necessary, you must place a piece of kraft paper between the pressed image and the hot iron. Failure to do this will result in a melted transfer.

The IColor™ Presto! 2 Step™ Transfer Paper was developed specifically for the IColor™ series of transfer printers, but **can be used interchangeably** with most other toner based printers (check with the manufacturer to be certain).

IColor™ 2 Step Presto! Transfer Media is used as a set, comprising of a 'Colored Transfer Sheet' and an 'Adhesive Sheet'

RECOMMENDED COLOR SETTINGS:

- IColor™ 650 / 600 / 560 / 550 / 540 / 500 Printers: Set cartridges to standard CMYK configuration with black cartridge.
 - When printing onto all colors or metallic paper options, set artwork color to: 100% Cyan, 100% Black
 - When printing onto neon paper options, set artwork color to: 100% Cyan, 100% Yellow
- CMYK Printers:
 - For all paper options, set artwork color to: Rich Black (100% Cyan, 100% Magenta, 100% Yellow, 100% Black)
- IColor™ 800 / Most Oki White Toner Printers:
 - When printing onto all colors or metallic paper options, set artwork color to: Composite Black (100% Cyan, 100% Magenta, 100% Yellow)
 - When printing onto neon paper options, set artwork color to: 100% Cyan, 100% Yellow
- Monochrome Printers:
 - For all paper options, set artwork color to: 100% Black with full density

INSTRUCTIONS FOR BEST RESULTS:

1. Place the Presto! transfer sheet into the appropriate tray of your printer.

- ⚠ The dull side is the print side.
- IColor™ 650 / 600 / 500 / Most Oki Printers: Print side face up in the Multipurpose tray
- IColor™ 560 / 550 / 540: Print side face down in the Bypass tray or print side face up in tray 1 (ProRIP defaults to bypass tray)
- IColor™ 800: Print side face down in the Bypass Tray
- ⚠ To avoid printer jams in Tray 1, stack a few sheets in the tray at once so the printer pulls the media cleanly.

2. Printer Settings:

In the RIP software settings, choose the paper type according to the printer being used. Make sure you are working CMYK queue in the ProRIP software or 'A' Configuration if using the TransferRIP software.

⚠ Specific print modes and sizes for this paper are available when using the IColor™ ProRIP software.

- Listed as 'UNINET IColor Presto! 2 Step Textile'
- The page size should match the size of the media being used (Letter, A4 or Tabloid).

Otherwise, use the following settings based on the printer:

- IColor™ 500 / 600 / Most OKI Printers: Set media type to 'Transparency'; and media weight to 'Ultra Heavy 1'
- IColor™ 650: Set media type to 'Transparency'; and media weight to 'Ultra Heavy 3'
- IColor™ 550 / 540: Set paper type to 'Thick to 163g'
- IColor™ 560: Set paper type to 'Thick to 105g'
- IColor™ 800: Set paper type to 'Thick to 163g' (Thick to 220g may be needed for extra heavy coverage)

⚠ If not already done automatically in the RIP, remember to set the job to **mirror print**, ensuring the correct orientation when transferred to the substrate.

3. Print the image.

4. **Preheat the press** to 285°F / 140°C and keep the press closed for at least **5 minutes** before proceeding to heat up the lower platen.

- **This step is extremely important** to ensure a good bond during the marrying process. Do not proceed until you feel the heat radiating from the bottom of the press platen, or you may experience incomplete transfers.

5. **Place the printed image in the middle of the press** with the printed side facing up.

- Place the adhesive sheet on top of the print, adhesive coated side down – the image and the adhesive should be face-to-face.
- Adhesive side is the non-marked, smooth, coated side.
- **TIP:** Fold a small corner of the adhesive sheet over, prior to pressing (this will make it easier to peel apart after pressing).

6. **Cover the two sheets** with kraft paper or a PTFE-based sheet and press the two sheets together in the heat press at 285°F / 140°C for 120 seconds with medium pressure.

7. **Open the press and immediately** (while hot) - rub the sheets with a piece of textile for **5 seconds**, then peel the adhesive sheet away from the transparent transfer sheet **diagonally** in one slow, low and fluid motion.

- This must be done with the sheets on the press to minimize heat loss. The use of heat resistant gloves will help keep the paper in place due to the temperature of the lower platen.
- **TIP:** In order to avoid a faulty peel, it is recommended to peel from the side of the image with the greatest toner density.
- **TIP:** For images with a lot of black print (especially when printing with the IColor™ 800W), it may be necessary to press for a longer period of time and increase the dwell time in order to achieve a clean adhesive pull
- **TIP:** Slow down at the end of the peel and allow the adhesive sheet to 'fall off' to ensure that you do not lose the last edge of the graphic.

8. **Observe the used adhesive sheet** – you will see the adhesive was removed only where toner was present on the transfer sheet.

- If you see any part of your design on the adhesive sheet, you did not get a clean pull. **See Tech Tips** for reasons why this may have happened.
- Examine the transfer sheet to determine if the transfer is acceptable and proceed to **Step 9**. Discard the used adhesive sheet.

9. **Trim off the edges** of the transparent transfer sheet using a pair of scissors or a cutting board. This will ensure no excess adhesive sticks to the garment and eliminate the chance of a white box around your design.

10. **Place or thread your garment on the press.** Position the transfer sheet (print side down) onto the garment.

- It is suggested that you use heat resistant tape to secure the sheet to the garment. Otherwise, opening the press can cause the transfer sheet to lift prematurely.
- For more precise placement, **lay the garment out on a table**, position the transfer sheet appropriately and tape the corners before placement on the press.

11. **Cover the transfer sheet** and garment with kraft paper or a PTFE-based sheet and press the garment using a heat press at 285°F / 140°C for 30 seconds with medium-high pressure for cotton textiles.

- If you are pressing onto 100% poly, press at 265°F / 129°C.
- If you are pressing onto 50/50 cotton/poly, press at 285°F / 140°C.
- You can perform **this step ONLY** as low as 250°F / 121°C if necessary to avoid dye migration on polyester fabrics, avoid damaging delicate textiles and to retain vibrancy.
- **TIP:** Pressing at a lower temperature in all cases will result in a more vivid final product.

12. **Remove the garment** from the heat press carefully and immediately lay flat. Allow it to cool for at least 5 minutes.

13. **Once the garment is completely cooled**, carefully peel away the transfer sheet in one smooth, continuous rolling motion.

- Removal while still warm could lead to an incomplete or faulty transfer.
- It is suggested that you start your pull from an area that has the most toner coverage. The image will adhere to the garment. Perform this step within 60 mins or less.

14. **Re-Pressing** (AKA post press or fixing press) the image into the garment is important for wash durability.

- Place the textile back on the heat press.
- Cover with kraft paper or IColor™ T. Seal.
- Re-press the image for roughly 20 seconds at 285°F / 140°C or at the temperature it was originally pressed.

15. **Wait 10 seconds before** removing the fixing or kraft paper to avoid any part of the transfer from sticking to the kraft sheet.

- **Pull slowly in one smooth, continuous motion.** It is important to wait before pulling the paper off, otherwise it could pull the design off the garment!
- **While the garment** is still on the press and still hot; lightly stretch the material to allow the toner to soak into the fabric to prevent cracking.

TECH TIPS

There are many variables that could produce different results. Specific steps may need to be altered based on:

- **Type of garment:** Cotton, Polyester, Spandex and Lycra material all respond differently to heat. All instructions are based on cotton garments.
 - **If your presses are not pulling cleanly,** preheat the lower platen of the press in the closed position for several minutes to retain the necessary heat to perform this step. Adjusting the color mix of the print may help as well. The better the density, the cleaner the pull.
 - **Type and brand of Heat Press:** The temperature and duration varies slightly based on the heat press being used. All instructions are based on using a Hotronix Fusion press (recommended). Clam shell and other types of swing away presses may also yield different results. Always place the transfer paper in the middle of your heat press. Some heat presses do not have uniform heat and pressure distribution, which can affect your final project.
 - **The following colors may be incompatible with the IColor™ 500, Oki C700 and C900 series:**
 - Silver metallic, white gold metallic, yellow gold metallic and black.
 - Each of these options may exhibit static issues, which present themselves as light print halfway down the page.
 - If you encounter this, you may optionally print on the adhesive media (do not mirror print) and then press the 2 sheets together as explained in step 5.
- ⚠ Printing on the adhesive media could cause a fuser jam, so do so at your own risk.
- ⚠ Only use kraft paper made for heat press applications! The use of butcher paper or other kinds not specifically designed for heat transfer applications can cause the image to stick to the paper.

If your transfer has stray adhesive on it after pressing to the adhesive (seen as clouding), it is suggested that you perform **Step 6** with medium-low pressure.

- This may be as a result of humidity affecting the adhesive sheet.
- If you wish to press this image to the textile, do so with medium-low pressure as well.

During Step 6 of these instructions, it is important that the adhesive sheet is placed on top because:

- The source of heat is on top and heat is transferred directly to the adhesive sheet instead of passing through the transfer sheet
- When pulling the sheets apart, the sheet on top tends to curl. If that was your transfer sheet, it would then be difficult to place on your garment and could be ruined if the image touched itself while hot.

During Step 7, note that the denser your image, the more difficult it will be to pull the A & B sheets apart. Start out with less dense, weeded or rasterized images to perfect your process. Full coverage images take some skill to successful pull cleanly and may require a longer press time and/or higher temperature. **Full coverage tabloid graphics are not recommended.**

If, during Step 8, your images are not peeling cleanly, first ensure that you are printing with the right amount of toner density in your image (at least 70%).

- If so, then preheat the bottom platen of your heat press to ensure it's hot enough. Cool lower platens are the main cause of inconsistent A/B pulls.
- If this still does not resolve the issue, consult the Humidity and Storage sections below.

- When pressing large areas of black (especially using the IColor™ 800W), it may be necessary to increase the press time from 120 sec to 200 sec because of heavier than normal toner coverage. Increasing the dwell time before pulling will also help with adhesion.

If, during Step 11, you are adjusting the heat press temperature to accommodate delicate material, you must increase the temperature to 310°F / 154°C for **Step 6**. The adhesive will not transfer over properly if set at a lower temperature. Using two heat presses would greatly increase your output and is recommended.

For Cotton / Poly blends and hoodies:

- Press at 250°F / 121°C for 20 seconds, cool immediately and roll the transfer sheet off very tightly.
- Re-press for 15 seconds and cool immediately. A lower press temperature and immediate cooling are necessary to prevent dye migration.

If you are seeing stray adhesive sticking to your garment or substrate during the transfer **Step 11** of these instructions, try reducing the press pressure to ‘medium-low’ or ‘3’.

If some of your image isn’t sticking to the garment properly during **Step 13**, start your pull from an area that has the most toner coverage.

- For example, DO NOT start your pull from a dot or a small independent portion of your graphic. The more toner coverage, the higher the probability that you won’t lose part of your image when getting started.

Humidity Suggestions: If your transfers are incomplete (gaps or holes where the adhesive didn’t transfer over), then your adhesive sheets may have been affected by humidity. Follow these steps to remove the humidity:

- Place the adhesive sheet(s) face up in the heat press while hot.
- Do not press them, just allow to sit for approximately 1 – 2 minutes. Then proceed as normal.

Adhesive sheet storage: To prevent humidity from affecting your paper, store in a resealable bag. Adding a silica pack will help to absorb any moisture. Use of a de-humidifier will help reduce excess moisture.

Optimal Humidity Level: 45% - 65%

- Regulated with A/C, a humidifier or de-humidifier, depending on current atmospheric conditions.

Optimal Temperature Range: 50°F / 10°C - 75°F / 24°C

Transfer sheet storage: If the paper is sticking together due to static electricity, store in a resealable or anti-static bag. Adding a dryer sheet will help reduce the static. Fan out the paper before loading into the printer to ensure proper feeding.

There are many types of coatings and finishes applied to textiles and synthetic fabrics, so **make certain adhesion** is satisfactory and test for washability or scuff-resistance when applying transfer paper to such materials.

It is recommended to **wash finished garments inside out** in cold or warm water and low agitation. Avoid fabric softener, as it may prematurely degrade the transfer. Tumble dry on low setting - For best results, hang to dry. If ironing is necessary, you must place a piece of kraft paper between the pressed image and the hot iron. Failure to do this will result in a melted transfer.

To see video instructions for IColor™ Presto! 2 Step™ Transfer Paper, visit www.icolorprint.com/video

ALSO AVAILABLE:

- IColor™ Premium 2 Step Transfer Paper for light and dark colored garments
- IColor™ Select and Select Ultra Bright 2 Step Transfer Paper for light and dark colored garments
- IColor™ Standard 2 Step Transfer Paper for light and dark colored garments
- IColor™ Glitter Adhesive 2 Step Transfer Paper (for use with IColor™ Standard 2 Step Transfer Paper)
- IColor™ Light 1-Step Transfer Paper for light colored garments
- IColor™ Presto 2 Step Transfer Paper for textiles and hard surfaces
- IColor™ Temporary Tattoo 2 Step and Easy Tattoo Transfer Paper
- IColor™ Classic, Premium, Wood and Leather and Ceramic Hard Surface 1-Step Transfer Paper
- IColor™ AquaClear 1-Step Transfer Paper for candles and other substrates not resistant to heat
- IColor™ Label / Sticker Paper (Clear and White) in Letter and Tabloid size
- IColor™ Window Cling Media (Clear and White) in Banner and cut sheet options
- IColor™ Banner Paper
- IColor™ Magnetic Media in Letter and Tabloid size

...and more! Contact your dealer for more information.

IColor™ Transfer Paper Comparison Charts

ICOLOR TEXTILE TRANSFER PAPER

ATTRIBUTE	PREMIUM	PREMIUM STRETCH	STANDARD	SELECT UB	SELECT	PRESTO	LIGHT	SPEEDTRANS LIGHT
PROCESS	2 Step	2 Step	2 Step	2 Step	2 Step	2 Step	1 Step	1 Step
DURABILITY (# of Washes @ 104 °F/40 °C)	Up to 100	Up to 100	50+	50+	50+	50+	15+	15+
DARK TEXTILES (BRILLANCE)	BEST	BEST	BETTER	BEST	GOOD	BETTER	FAIR	FAIR
DELICATE TEXTILES	BEST	BEST	GOOD	GOOD	GOOD	GOOD	NOT RECOMMENDED	NOT RECOMMENDED
STRETCHABILITY	BETTER	BEST	GOOD	BEST	BEST	GOOD	GOOD	GOOD
FINISH	MATTE	MATTE	SEMI GLOSS	MATTE	MATTE	SEMI GLOSS	SATIN	SATIN
TRANSFER 'A' SHEET CHARACTERISTIC	OPAQUE	OPAQUE	TRANSPARENT	TRANSPARENT **	TRANSPARENT	OPAQUE	OPAQUE	OPAQUE
PRESS TEMPERATURE (°F/°C)	250°F / 120°C	285°F / 140°C	310°F / 154°C	310°F / 154°C	310°F / 154°C	285°F / 140°C	390°F / 200°C	375°F / 190°C
PRESS TIME	30 + 30 secs	45 + 10 secs	120 + 30 secs	120 + 25 secs	120 + 25 secs	120 + 30 secs	15 secs	10 secs
SOFT HAND	BEST	BEST	GOOD	GOOD	GOOD	GOOD	BETTER	BETTER
COST	\$\$\$	\$\$\$	\$\$	\$\$	\$\$	\$\$	\$	\$

** Select 800 Ultra Bright has an opaque 'A' sheet

ICOLOR HARD SURFACE TRANSFER PAPER

ATTRIBUTE	PREMIUM	CLASSIC	CERAMICS	WOOD/LEATHER	PRESTO! HARD SURFACE	PRESTO! PAPER/WOOD	AQUACLEAR	TATTOO
PROCESS	1 Step	1 Step	1 Step	1 Step	1 Step	1 Step	1 Step	2 Step
DURABILITY (RESISTANT TO SCRATCHING/CHIPPING)	BEST	BEST	BEST	BEST	BEST	BEST	GOOD	BETTER
COLOR BRILLANCE	BETTER	BETTER	BETTER	BETTER	BEST	BEST	BETTER	BETTER
METALLIC FINISH	NO	NO	NO	NO	YES	YES	NO	NO
PRESS TEMPERATURE (°F/°C)	300°F / 150°C *	300°F / 150°C *	300°F / 150°C *	300°F / 150°C *	320°F / 160°C *	265°F / 130°C *	N/A	265°F / 130°C
PRESS TIME	60 SECS *	60 SECS *	180 SECS *	60 SECS *	180 SECS *	90 SECS *	N/A	40 SECS
ACRYLIC	YES	YES	YES	YES	YES	NO	YES	YES
METAL	YES	YES	NO	NO	YES	NO	YES	YES
CERAMIC	YES	YES	YES	NO	YES	NO	YES	YES
TILE	YES	YES	YES	NO	YES	NO	YES	YES
GLASS	YES	YES	YES	YES	YES	NO	YES	YES
CRYSTAL	YES	YES	YES	YES	YES	NO	YES	YES
PAPER/WOOD/CARDBOARD	YES	YES	NO	YES	YES	YES	NO	YES
LEATHER	YES	YES	NO	YES	NO	NO	NO	YES
CANDLES	NO	NO	NO	NO	NO	NO	YES	YES
FLESH	NO	NO	NO	NO	NO	NO	NO	YES
COST	\$	\$	\$	\$	\$\$	\$\$	\$\$	\$\$\$

* Temperature and press time varies based on substrate

May 2023 Revision - A newer version of this manual may be available at www.icolorprint.com/support

(Or scan this QR Code)

