ProSeal™

V3 MATTE FINISH Finishing Liquid

Instructions for DTF & White Toner Transfers



1 Print and Transfer Your Design

Prepare and apply your transfer according to the instructions for your printing system and transfer media.

For DTF: Print your design, **apply DTF adhesive powder**, cure, and heat press the transfer onto the garment using the recommended settings and protective covering.

For White Toner: Print your design, complete any required adhesive-paper step, and heat press the transfer onto the garment **according to the transfer** paper's instructions.



2 Peel Away the Transfer Film or Paper

After pressing, **peel away** the DTF film or white toner transfer paper according to its instructions.
Leave the transferred design on the garment before applying **ProSeal™ V3 MATTE FINISH Finishing Liquid**.



3 Apply ProSeal™ V3 MATTE FINISH Finishing Liquid

Hold the spray bottle approximately **10 inches** from the transferred design and apply a light, even mist. Use approximately **1–2 sprays for smaller designs** or **2–3 sprays for larger designs**, ensuring even coverage.



4 Finish with a Second Press

Cover the design with a **PTFE Finishing sheet** and heat press for **15 seconds**.
FOR BEST RESULTS: Use a **ProSeal™ Finishing Sheet** for the most durable, premium hand feel, and stretchable garment possible.

Benefits

- **Improved Hand Feel**
- **Improved Breathability**