

### 1. Download the installation file

- ProRIP Essentials - [www.icolorprint.com/pe](http://www.icolorprint.com/pe)
- Absolute White RIP - [www.icolorprint.com/awr](http://www.icolorprint.com/awr)
- SmartCUT - [www.icolorprint.com/sc](http://www.icolorprint.com/sc)

### 2. Software Validation

- Visit the UNINET IColor Validation website. [www.icolorprint.com/get-support/validate-rip-software](http://www.icolorprint.com/get-support/validate-rip-software)
- Note your unique System ID.

For drivers and manuals please visit:  
[www.icolorprint.com/setup](http://www.icolorprint.com/setup)

UNINET IColor Software Validation

Validation (visit site below to validate)

[Click to visit UNINET IColor Validation Site](#)

Product:  
UNINET IColor Software

Serial Number

System ID  
XXXXXXXXXX

Validation Code

Validate

Exit (Run In Demo Mode)

### 3. Software Validation

- Enter your provided serial number
- Enter your System ID
- Then select Get Validation Code

**Validation portal for Dongleless versions of UNINET® ProRIP Essentials RIP, Absolute White RIP, and SmartCUT Software**

Please read before validating:

- You only need to validate your computer to run the RIP ONCE. Uninstalling the software does NOT remove the validation from your system. You can re-install or upgrade the software as many times as necessary without losing validation as long as it's on the same computer.
- Each serial number provides 3 validations (not 3 licenses). Each serial number is a license to run the RIP on one computer only. The extra validations are issued to provide redundancy in case of accidental loss of validation due to hardware failure (hard-disk crashes, etc.) or other unforeseen events.

Product Code (Serial Number)  
U198663XXXXXXXXXX

System ID  
2049071705

Get Validation Code

Do not press submit more than once

### 4. Software Validation

- After obtaining the validation code, please enter your codes into the Validation module
- Then select Validate

**Validation portal for Dongleless versions of UNINET® ProRIP Essentials RIP, Absolute White RIP, and SmartCUT Software**

**Here is your validation code. Please copy this code into your UNINET IColor software validation window and click on Validate to finish.**

Serial Number: U198663XXXXXXXXXX  
 System ID: 2049071705  
 Validation Code: 9A9BXXXXXX  
 Validations Remaining: X

UNINET IColor Software Validation

Validation (visit site below to validate)

[Click to visit UNINET IColor Validation Site](#)

Product:  
UNINET IColor Software

Serial Number  
U198663XXXXXXXXXX

System ID  
XXXXXXXXXX

Validation Code  
9A9BXXXXXX

Validate

Exit (Run In Demo Mode)

UNINET IColor Software Validation

Validation (visit site below to validate)

[Click to visit UNINET IColor Validation Site](#)

Product:  
UNINET IColor Software

Serial Number  
U198663XXXXXXXXXX

Validation Successfull

OK


Validate

Exit (Run In Demo Mode)




## 5. Absolute White RIP - Unlimited Prints Activation

• After validation, to unlock Unlimited Prints, open program settings.



• Select "Activate Unlimited Prints"



• Enter your Unlimited Prints Unlock Code

