

iColor® 1-Step AgnaClear Media for Hard Surfaces

Part # ICHAC

iColor® 1-Step AquaClear transfer media is an easy to use, all-in-one transparent media for use with various substrates and hard surfaces such as candles, ceramic, glass and more! Please follow the steps below for best results:

- 1. Place transfer sheet into the appropriate tray of the **iColor®** printer, print side up or down, depending on your model (the glossy side of this media is the print side).
- 2. Paper type should be 'Heavy' and page size should be 'Letter'. DO NOT set the job to mirror print.
- 3. If using the iColor® TransferRIP or ProRIP Software, add 200% 300% white underprint if applying to clear or dark surfaces.
- 3. Print the image.
- 4. Cut the image out as closely as possible.
- 5. Dip the image in water for approximately 30 seconds. The paper will roll up; this is normal.
- 6. Remove from the water and rub the image between your thumb and pointer finger to remove the carrier tape.
- 7. Affix the image to the substrate and brush it with your finger or a piece of plastic to remove any air bubbles.
- 8. Remove any excess water and let dry for three hours.

Also available:

iColor® 1-Step LIGHT and SPEED TRANS LIGHT Transfer Media for light colored garments

iColor® 2-Step **Standard** Transfer Media for light and dark colored garments

iColor® 2-Step GLITTER Adhesive Transfer Media (for use with iColor® 2-Step Standard Transfer Media)

iColor® 2-Step *Premium* and *Premium* STRETCH Transfer Media for light and dark colored garments

iColor® 2-Step Presto! Transfer Media for textiles and hard surfaces

iColor® 1-Step CLASSIC, Premium, WOOD AND LEATHER and CERAMIC Hard Surface Transfer Media

iColor® 2-Step Temporary Tattoo Transfer Media

...and more! Contact your dealer for more information.

January 2018 Revision - A newer version of this manual may be available at www.icolorprint.com/support